

**UMD 96**  
**Multifunctional Meter**  
 Manual  
 (FW 2.0.40, 6/2016)



## 1. Instrument Connection

### 1.1 Physical

The UMD 96 instrument is built in a plastic box to be installed in a distribution board panel. The instrument's position must be fixed with locks.

Natural air circulation should be provided inside the distribution board cabinet, and in the instrument's neighbourhood, especially underneath the instrument, no other instrumentation that is source of heat should be installed or the temperature value measured may be false.

### 1.2 Power Supply

The supply voltage (in range according technical specifications) connects to terminals AV1 (No. 9) and AV2 (10) via a disconnecting device (switch – see wiring diagram). It must be located at the instrument's proximity and easily accessible by the operator. The disconnecting device must be marked as such. A circuit breaker for nominal current of 1 amp makes a suitable disconnecting device, its function and working positions, however, must be clearly marked. A connection cable maximum cross section area is 2.5 mm<sup>2</sup>.

In case of DC supply voltage, the polarity of connection is generally free, but for maximum electromagnetic compatibility the grounded pole should be connected to the terminal AV2.

### 1.3 Measured Voltages

The phase voltages measured are connected to terminals L1 (12), L2 (13), L3 (14), the common terminal to connect to the neutral wire is identified as N (11; it stays free at delta- (3-D) and Aron- (A) connections). It is suitable to protect the voltage lines measured for example with 1A fuses. Measured voltages can also be connected via instrument voltage transformers.

A connection cable maximum cross section area is 2.5 mm<sup>2</sup>.

### 1.4 Measured Currents

The instruments are designed for indirect current measurement via external CTs only. Proper current signal polarity (S1, S2 terminals) must be observed. You can check the polarity by the sign of phase active powers on the instrument display (in case of energy transfer direction is known, of course).

The current signals from 5A or 1A (or 0.1A for the „X/100mA“ models) instrument current transformers must be connected to the terminal pairs I11, I12, I21, I22, I31, I32 (No. 1 ÷ 6). In the P.01 parameter (see below), set the CT-ratio.

The I2 terminals stay free in case of the Aron (A) connection.

A connection cable maximum cross section area is 2.5 mm<sup>2</sup>.

## 2. Basic Operation

On connecting power supply the display shows all of the segments, then gradually screens with the instrument type and setting of basic parameters

1. line 1: **133** - instrument type number
- line 2: **5A** - current input type
- line 3: **rl** - digital output type : relay ( **r** ), pulse ( **l** ), or none ( **n** )
1. when connection of voltage via voltage transformers set (otherwise the screen is skipped) :

1. line 1: **U<sub>E</sub>** - voltage transformer connected identification  
line 2: nominal primary voltage [kV]  
line 3: **0.1** nominal secondary voltage [kV]
2. line 1: **C<sub>E</sub>** - current transformer/range specification  
line 2: nominal primary current [A]  
line 3: nominal secondary current [A]
3. line 1: **F<sub>U</sub>** - nominal frequency and voltage  
line 2: nominal frequency  
line 3: nominal voltage


Then the instrument starts display actual measured values. Simultaneously, if the instrument has a communication line, it can be set and its measured values read via the communication link using a PC.

## 2.1 Setup

At this moment it is necessary to set *instrument parameters* that are essential for proper instrument measurement :


- CT ratio – parameter 01 (and its multiplier, optionally)
- type of connection – parameter 02 (wye, delta, Aron)
- mode of connection – parameter 04 (direct or via VT connection, VT ratio and multiplier, optionally)
- nominal frequency  $f_{NOM}$  and nominal voltage  $U_{NOM}$  – double parameter 05

Usually, it is only necessary to adjust the CT ratio. Next example shows how to do it :

Assuming that the ratio of used CTs is 750/1 A. First off all, it is necessary to switch display from measured data branch (the ULN screen on the example below) to the *parameter branch* with the **P** button. The branch is indicated with the  symbol. Parameter 01 appears – this parameter is the CT ratio and its default value is 5/5 A.

Now enter editing mode by pressing and holding the **P** until the value gets flashing.

As soon as the value flashes, release the **P**. Now you can change it. Increase primary value



by pressing of the **▲**. If you keep it pressed two-speed autorepeat helps to reach target value quickly. Then use multiple pressing of **▲** and **▼** for fine setup.

To change the secondary value, simply press the **M**. The button serves as toggle switch between 5 and 1.

### CT Ratio Change Procedure Example



Target CT value is prepared now and we can leave the edit mode with () pressing the **P**. The value is stored into the instrument memory and the flashing stops.

Now return to so called *main parameter branch* (see below) with next pressing the **P** and then you can scroll to other parameters with **▲** and **▼** and edit them in a similar way or you can return to the measured data branch with the **M**.

The summary of all instrument parameters is stated in the table below. Their description is stated in following chapters.

## 2.2 Measured Data

The instrument starts display actual measured values on power-up. The screen that was selected before the last powerdown is displayed. You can navigate through all of measured and evaluated values with **▲**, **▼** and **M** buttons as shown on *the Measured Data Navigation Chart* below.

If phase values displayed, individual L1 / L2 / L3 - phase value is shown in the line 1 / 2 / 3. If a three-phase value is displayed, it is shown in the line 2 and the  $\Sigma$  symbol appears.

The quantities' meaning and evaluation formulas can be found in the appropriate chapter further below.

Most of data are arranged in four columns :

- Actual ..... actual values, refreshed each 3 measurement cycles (30/36 mains cycles)
- Avg ..... average values per appropriate averaging period (see below)
- AvgMax ... maximum of the avg-value reached since the last clearing
- AvgMin .... minimum of the avg-value reached since the last clearing

You can scroll inside a column down and up with the **▲** and **▼** keys and move horizontally from a column to the next right one cyclically with the **M** key.

Exception : Only actual values of harmonics and electrical energy are available. These values are arranged in different way – see further below.

## 2.3 Average Values

Average values are processed according set averaging method and length of averaging window (individually for "UI"-group and "P/Q/S"-group of quantities). Maximum and minimum values of them are registered into the instrument's memory. The maximums are displayed in the "AvgMax" column and they are identified with the **▲** symbol in the front of the value. Analogically, the minimums in the "AvgMin" column are identified with the **▼** symbol.



Neither maximum nor minimum of  $\cos\phi$  values are evaluated due to special character of the quantity. Similarly, these extreme values are not evaluated at harmonics

You can clear the "AvgMax"/"AvgMin" values. All of the maximums/minimums of appropriate quantity group are cleared simultaneously. To do it, follow next :

- navigate on corresponding AvgMax or AvgMin value
- press the **M** key until the value starts flashing
- with the **▲** or **▼** key, choose the option **CLR**
- then confirm by pressing the **M**

The appropriate group (U/I or P/Q/S) of average maxs/mins is affected by single clearing only ! Each group must be cleared individually.  
If the instrument is locked, the clearing is not possible.

## 2.4 Full Spectrum Values P/Q/PF & Fundamental Harmonic Values P<sub>fh</sub> / Q<sub>fh</sub> / cos φ

As standard, active and reactive powers (and therefore power factor) are evaluated from full spectrum of harmonic components of both voltage and current. Sometimes (for example for power factor compensation system checking), it is useful to know fundamental harmonic part of these quantities too. Such quantities are marked P<sub>fh</sub>, Q<sub>fh</sub>, cos φ.

As you can see on the navigation chart you can navigate from the full spectrum values branch with the **M** key further right into the fundamental harmonic values branch and vice versa. To distinguish actual displayed branch, the H symbol is displayed for the fundamental harmonic branch.

Exception : Actual values only of fundamental harmonic power factor – the cos φ – are evaluated (no average values available). Next, this fundamental harmonic power factor can be expressed not only as cos φ, but as tan φ or φ too, depending on setting of parameter 09.

## 2.5 Fundamental Harmonic Power Factor Formats cos φ / tan φ / φ

The fundamental harmonic power factor can be expressed not only as cos φ, but as tan φ or φ too, depending on setting of parameter 09.

For outright specification of the quadrant, the power factor of the fundamental harmonic component is accompanied with two attributes :


- a sign (+ or -), which indicates polarity of appropriate active power
- a symbol **€** or **≠**, which indicates the power factor character

At the following figures there are examples of three-phase fundamental power factor presentations :

Fundamental Harmonic Power Factor Formats



- the left figure : Σ cos φ = 0.98 inductive (choke symbol displayed). Furthermore, active three phase power is being negative, therefore the leading "minus"-sign ( and the **€** symbol displayed )
- the middle figure : Σ tan φ = 0.20 inductive. Active three phase power is positive.
- the right figure : Σ φ = 8 degrees inductive. Active three phase power is positive.



On the figure on the left, there is phase cos φ values example :

- cos φ1 = 0.97 inductive. L1-phase active power is currently negative (because of leading "minus"-sign)
- cos φ2 = 0.94 inductive ( L2-phase active power currently positive )
- cos φ3 = 0.99 capacitive ( L3-phase active power currently positive )

## 2.6 THDs and Harmonic Components

You can check actual values of both voltage and current THDs and harmonic components in appropriate rows (see the Measured Data Navigation Chart).

When you scroll to one of this rows, THD values of all measured phases are displayed as default. Symbols THD - V - LN or THD - A indicate phase voltage or current THD values, respectively.

With the **M** key you can switch to harmonic components. The symbol H appears, indicating harmonic components (of voltage or current). Symbol % means that the values are expressed in percent of fundamental harmonic component. Order of harmonics just displayed flashes periodically in the display middle line – for example, string H03 means 3<sup>rd</sup> harmonics.

By repetitive pressing of the **M** key you can check other harmonics. Although the instrument evaluates all of the harmonic components up to 40<sup>th</sup> order internally, only odd components to 25<sup>th</sup> order can be viewed of its display (full spectrum of the harmonics is available via communication interface only).

## 2.7 Electricity Meter

Electricity meter comprises three-phase energy data and maximum three-phase active power demand value. The values are situated in particular row.


Depending on the parameter 08 setup, two electricity meter display modes can be chosen :

- "4E+Pmax" mode (default)
- "8E" mode

### 2.7.1 "4E+Pmax" Display Mode

In this mode, first four windows contain three-phase energies of four-quadrants :

- ΣEP+ ... three-phase imported active energy, indicated with Σ - kWh (or MWh or kWh = GWh)
- ΣEP- ... three-phase exported active energy, indicated with Σ - kWh and preceding – sign
- ΣEQL ... three-phase inductive reactive energy, indicated with Σ - kVArh – L
- ΣEQC ... three-phase capacitive reactive energy, indicated with Σ - kVArh – C



Each value occupies all of three display lines, 8 digits before the decimal point and one after it. For the example at left, ΣEP+ = 293745.8 kWh.

The values are registered since the last clearing. To clear the energies, display any of them and then follow the same procedure as for max/min average values. All of the energies are cleared simultaneously and start to count from zero again.

In the 5<sup>th</sup> window there is

- ΣPavgmaxE ... maximum of three-phase average active power (power demand), indicated with Σ - kW - ▲ and bar over the value

The value contains maximum of three-phase average active power since the last clearing. Averaging method and averaging period for this value can be set regardless of the method of standard average values, described above. The quantity is marked with the "E" letter to distinguish from the standard maximum average quantities.

Similarly as the energies, the value can be cleared independently.



- If the instrument is locked, clearing is not possible.
- If the instrument is equipped with a communication interface, the values can be cleared remotely.

## 2.7.2 "8E" Display Mode

In this mode, reactive energies registered separately depending on actual three-phase active power ( $\Sigma P$ ) sign are displayed ("six-quadrant" mode; such format can be convenient for renewable sources monitoring, for example):

- $\Sigma EP+$  ... three-phase imported active energy, indicated with  $\Sigma$  - kWh (or MWh or kWh = GWh)
- $\Sigma EP-$  ... three-phase exported active energy, indicated with  $\Sigma$  - kWh and preceding - sign
- $\Sigma EQL+$  ... three-phase inductive reactive energy registered during the  $\Sigma EP$  value was positive (import); indicated with  $\Sigma$  - kVarh - L
- $\Sigma EQL-$  ... three-phase inductive reactive energy registered during the  $\Sigma EP$  value was negative (export); indicated with  $\Sigma$  - kVarh - L and preceding - sign
- $\Sigma EQC+$  ... three-phase capacitive reactive energy registered during the  $\Sigma EP$  value was positive; indicated with  $\Sigma$  - kVarh - C
- $\Sigma EQC-$  ... three-phase capacitive reactive energy registered during the  $\Sigma EP$  value was negative; indicated with  $\Sigma$  - kVarh - C and preceding - sign





Furthermore, energies in VAh are available too:

- $\Sigma ES+$  ... three-phase apparent energy registered during the  $\Sigma EP$  value was positive; indicated with  $\Sigma$  - kVAh
- $\Sigma ES-$  ... three-phase apparent energy registered during the  $\Sigma EP$  value was negative; indicated with  $\Sigma$  - kVAh and preceding - sign

The three-phase active power demand  $\Sigma P_{avgmaxE}$  is not displayed in this mode.


## 2.8 Instrument State Symbols


Except of measured data, the instrument indicates following states with dedicated symbols:

-  ..... Export of three-phase active power. Displayed when the  $\Sigma P$  value is negative.
-  ..... A1(top) and A2 (bottom) alarm lights off / on. See output setup below.
-  ..... I1 digital input state is active.
-  ..... Instrument parameters are displayed.

## 2.9 Instrument Parameters

For proper operation in particular conditions, the instrument must be set. The instrument setup is determined using parameters, for example the current transformer [CT] conversion, type of measured voltage connection (direct connection or via a voltage transformer [VT] and its ratio), and connection configuration (wye / delta / Aron). Overview of all the parameters is listed in the table below.

To check or edit the parameters, press the **P** key. As default, parameter group 01 is displayed and symbol  (wrench) indicates, that setup data are displayed now.



The parameters are arranged in groups, numbered from 00 up. The number of group is displayed in the first line in format  $-P.nnn$ . (with preceding dash). You can browse through the parameter groups with the **▲** or **▼** keys.

If one parameter only in the group, its value is in the bottom line as shown at the example (nominal power 400 kVA).





If two parameters in the group, usually the first of them is displayed in the 2<sup>nd</sup> line and the second in the 3<sup>rd</sup> line (nominal frequency 50 Hz and nominal voltage 230 V).

To edit a particular parameter, scroll to its group. Then press and hold the **P** until the value gets flashing. Now release the key and set target value with the **▲** or **▼**, or the **M** key for some of parameters. You can use autorepeat function by keeping one of the arrow keys pressed too. Finally, press the **P** and the value is stored into the memory.

If more parameters in the group, the first one is chosen when entering editing mode for the first time. If you want to modify the second parameter only, simply cancel editing of the first parameter without any change and reenter the editing again – now the second parameter is chosen.

To return back to measured values display, simply press the **M** key.

#	parameter group	range	default	comment
00	lock	LOC / OPN	OPN	see Instrument Setup Locking / Unlocking
01	CT – ratio, multiplier screen 1 : row 2 : nominal primary current row 3 : nom. secondary current (for models "X/100mA", "X/333mV" fixed) screen 2 : MUL – current multiplier	primary : 1A ÷ 10 kA sec. : 5A / 1A (0.1A) (0.1 A, 0.333 V) 0.001 ÷ 999	5 / 5 A  1	secondary current selection with the <b>M</b> key par. placed in side branch if the current multiplier different from 1 the <b>▲</b> / <b>▼</b> flashes
02	connection type	3Y / 3D / 3A	3Y	
04	conn. mode: direct (---) or VT–ratio, mult. screen 1 : row 2 : primary U [ kV ] row 3 : secondary U [ kV ] screen 2 : MUL – voltage multiplier	0.001 ÷ 65 kV 0.001 ÷ 0.999 kV 0.001 ÷ 999	direct ( - - - )  1	parameters placed in side branch if the voltage multiplier different from 1 the <b>▲</b> / <b>▼</b> flashes
05	fNOM, UNOM row 2 : fNOM [ Hz ] row 3 : UNOM [ V / kV ]	50 / 60 Hz 50 V ÷ 1MV	50 230	UNOM value depends on connection mode : - direct : line-to-neutral - via VT : line-to-line
06	$\Sigma PNOM$ [ kVA / MVA ]	1 kVA ÷ 999 MVA	-	
07	averaging period row 2 : for U/I group row 3 : for P/Q/S group	0.01 ÷ 60 (1 sec ÷ 60 mins)	1 min 15 min	floating window type averaging method applied as default; thermal method indicated with symbol <b>▲</b>

08	avg period for $\Sigma P_{avgmaxE}$ , EI-meter d. mode line 2 : averaging period for $\Sigma P_{avgmaxE}$ , line 3 : Electricity meter display mode	0.01 ÷ 60 (1 sec ÷ 60 mins) "4E+Pmax" / "8E"	15 min "4E+ Pmax"	floating window type averaging method applied
09	fund. harmonic PF display format	cos / tan / fi	cos	
10	backlight	AUT / ON	ON	AUT-mode : the backlight is switched off automatically after app. 5 mins if no key is pressed
11	output setup row 2 : output O1 row 3 : output O2  standard type : "-O-"  pulse type : pulses / kWh(kvarh) control energy symbol : • none ... $\Sigma EP+$ • - ... $\Sigma EP-$ •  ... $\Sigma EQ$ •  ... $\Sigma EQC$	" - - - " = off  "-O-" = standard output  0.001 ÷ 999000 = pulse output	- - - ( off )	control energy selection with the  key Standard type output can be set via communication line only, not from instrument panel. Symbol  indicates different setup of the alarm light A1 from the O1 and the A2 from the O2 If pulse type output set from instrument panel, the A1 and the A2 alarm lights are set identically as the O1 and the O2, respectively.
15 (16)	communication interface 1 (and 2, opt.) for RS-485 (M-Bus) : screen 1: row 2 : address row 3 : rate [ kBd ] screen 2: Prt (protocol) – databits & parity for Ethernet: screen 1 : DHCP screen 2 ÷ 5 : IP1 ÷ IP4 (IP) screen 6 ÷ 9 : MA1 ÷ MA4 (Subnet Mask) screen 10 ÷ 13 : Gt1 ÷ Gt4 (Gateway)	1 ÷ 255 2.4 ÷ 460 (2.4 ÷ 9.6) 8 / 9-n / 9-E / 9-0  ON / OFF 0 ÷ 255 0 ÷ 255 0 ÷ 255	1 9.6 (2.4) 8 (9-E)  OFF 10.0.0.1 255.255.255.0 10.0.0.138	parameters placed in side branch
19	instrument status (read only) row 2 : failure specification row 3 : serial no. & instr. version (scroll)	0 ÷ 255 -	0 -	r. 2 : 0 = failure-free r. 3 : S...serial no. F... firmware version b...bootloader version H...hardware version

## 2.10 Instrument Setup Locking / Unlocking

When shipped, parameter editing is unlocked, that means :

- all of the parameters can be edited
- standard average maximums / minimums, electricity meter energies  $\Sigma EP+$ ,  $\Sigma EP-$ , etc., and electricity meter maximum power demand  $\Sigma P_{avgmaxE}$  can be cleared

After being put in operation, such operations can be locked (=disabled) to protect the instrument against unauthorized changes. Then operator can only check measured values and parameters, but cannot change anything, excluding special parameter No. 00, that serves as the instrument lock. It has one of two values :

**LOC** ..... instrument is locked  
**OPn** ..... instrument is unlocked (open)

If the instrument is locked, you can unlock it using the following procedure, which is similar to editing of other parameters:

1. Press the **P** key and scroll to parameter group 00 with arrow keys – value **LOC** is displayed.
2. Press the **P** and hold it down until the value is replaced with flashing number between **000** and **999**. As an example, you can imagine flashing **345** is displayed.
3. Press the following sequence: **▲ ▲ ▼ ▼**. The value changes gradually to **344.345.346.345** so the same value is shown at the end as at the beginning.
4. Press the **P**. The flashing number is replaced with **OPn** indicating unlocked state.

The digit shown while entering the unlocking keypress sequence is random and it is not important for correct unlocking (it is there only to confuse). Only the sequence of keys pressed is important and must be followed exactly.

The instrument can be locked in a way analogous to unlocking but it is necessary to press any keypress sequence that is different from the unlocking sequence noted above.

## 2.11 Display Contrast


Although the display contrast is temperature compensated, there can be sometimes necessary to tune it slightly. To do it, press keys **▲** and **▼** simultaneously and keep pressed. Then message

**CON** appears in the first line and the contrast value in the second one.

Now, if the display too light, keep the **▼** pressed and increase with repetitive pressing of the **▲** key.

Likewise, if too dark, keep the ▲ and adjust with the ▼ key. Finally, release the keys and new contrast is set.

## 2.12 Digital Outputs & Input



Instruments can be optionally equipped with a combination of outputs and inputs. Following inputs & outputs are available :

- two digital outputs – *relay* ( electromechanical, R ) or *impulse* (solid-state, I )
- one digital input

Furthermore, all of instrument models feature two "alarm " lights A1 and A2 for indication of various states, that can be considered as other special digital outputs. Function of these lights can be set in the same way as at standard digital outputs.

The behaviour of digital outputs can be programmed according to requirements as :

- *transmitting electricity meter impulse output mode*
- *standard output mode* , e.g. as a simple two-position controller or a defined status indicator
- *remote controlled output mode* ( by an external application via a communication link )

The digital input I1 state is indicated with the ⚡ symbol and can be used for state monitoring via a communication link.

### 2.12.1 Outputs & Input Connection

Digital inputs & outputs are connected to terminals on a rear panel of an instrument according to the following table. A connection cable maximum cross section area is 1.5 mm<sup>2</sup>.

Connection of Digital Outputs & Input







pin No.	signal
15, 16	O1A, O1B ... digital output O1
17, 18	O2A, O2B ... digital output O2
19, 20	I1A, I1B ..... digital input I1


All of digital outputs and input are *isolated not only from instrument internal circuits but mutually too*. Connected signals magnitude must correspond with the I/O technical specifications. The signal polarity is free. A connection cable maximum cross section area is 2.5 mm<sup>2</sup>.

### 2.12.2 Outputs Setup

Digital outputs ( including alarm lights ) function can be set either as *standard output* or as *electricity meter impulse output*.

The O1 / O2 output function can be checked in parameter group 11. Possible setup options are :

-  ... the output O1/2 is disabled
-  ... the output O1/2 is set to standard output mode (detailed setup available using the ENVIS program via a communication line only)
-  ... the output O1/2 is set to impulse output mode with nnn pulses per kWh; the control quantity is ΣEP+ (no symbol shown). Other control quantities options according accompanying symbol :
  -  ... ΣEP-
  -  ... ΣEQL
  -  ... ΣEQC



Example :

Output O1 : set to standard output mode (details via communication link only)

Output O2 : set to pulse mode, 20 pulses/kWh of energy ΣEP-

The standard output function can be used at instruments equipped with communication link only – it can be adjusted only via connected PC using ENVIS program ( see ENVIS program manual ). The impulse output function can be set simply from the instrument panel too.

The alarm lights A1, A2 setup is not displayed, it is available via a communication line only. You can only check if the setup is the same as corresponding O1/O2 setup or not. If any of signal lights A1, A2 is set, the outlines of both lights appear on the display. They stay hidden when function of both lights is disabled.


### 2.12.3 Impulse Output Mode

Any of digital outputs or alarm lights can be set as transmitting electricity meter. The frequency of generated impulses can be set depending on values of measured electric energy by the embedded electricity meter unit.



You can set to impulse output mode not only the I-type (solid-state) outputs, but the R-type (electromechanical relay) outputs too. But note lifetime of electromechanical relays, they have limited number of switchings.

The outputs O1/2 can be set to impulse output mode both manually from the instrument panel and remotely via a communication line. The manual setup is available in parameter group 11. After entering editation, set edited parameter (range 0.001÷999) with arrow keys and select desired energy with the M key.



Example :

Output O1 : 0.1 pulses/kWh = 1 pulse / 10 kWh, energy ΣEP+ (no additional symbol)

Output O2 : 5 pulses/kvarh, energy ΣEQL (due to symbol €)



By setting any of the O1/O2 outputs from the instrument panel, corresponding alarm light A1/A2 is set in the same way automatically too. Then the O1/O2 activity can be checked by the A1/A2 lights on the instrument display. Separate setup of the lights is available using the ENVIS program via a communication line only. If any of lights is set different from corresponding O1/O2 output the symbol ▲ preceding appropriate setup appears.



Even if an instrument is equipped with neither any digital output nor any communication line, you can set impulse function of alarm lights A1, A2 by setting the O1/O2 outputs.

After the impulse function mode is set, every 200 milliseconds the instrument executes evaluation of the measured electric energy. If the increment of recorded electric power is higher or equal to the quantity of power per one impulse, the instrument will transmit one or two impulses. The mentioned description shows that the fluency of impulse transmission is +/- 200 ms.

The impulse duty cycle is 50/50 ms (compliant with so-called SO-output definition), maximum frequency is 10 impulses per second.

## 2.13 Communication Interface

Monitoring the currently measured values and the instrument setup can using a remote computer connected to the instrument via a communication link. Such operation allows you to use all the setup options of the instrument, which it is not possible from the panel of the instrument.

Following chapters describe instrument communication links from the hardware point of view only. The detailed description of ENVIS program can be found in the program manual.

### 2.13.1 RS-485 Interface (COM)

The link is isolated from other circuits of the instrument. Use terminals A+ (No. 28), B- (29) and G (30). For instrument models with two links, the second link is connected as follows : A2+ (No. 31), B2- (32) and G2 (33).

Both of the links are insulated both from the instrument internal circuitry and mutually too, terminals No. 30 and 33 *are not connected internally* !

Standard setup for this interface is address 1, communication rate 9600 Bd and 8 bits protocol.

### 2.13.2 Ethernet Interface (ETH)

Using this interface the instruments can be connected directly to the local computer network (LAN). Instruments with this interface are equipped with a corresponding connector RJ-45 with eight signals (in accordance with ISO 8877), a physical layer corresponds to 100 BASE-T.

Each instrument must have a different IP- address, preset during the installation. The address can be set from the instrument panel or you can use the ENVIS-DAQ program. For detection of actual IP-address you can use *the Locator* function.

### 2.13.3 M-Bus Interface (M-BUS)

The interface is insulated from other instrument circuitry. Used signals are : M+ (No. 28), M- (29).

Standard setup for this interface is address 1, communication rate 2400 Bd and 9 bits with even parity protocol. Secondary address is BCD-coded instrument serial number.

## Technical Specifications

Measured Quantities			
Frequency			
fNOM- nominal frequency	50 / 60 Hz		
measuring range	40 ÷ 70 Hz		
Voltage			
model	„100“	„230“	„400“
UNOM (UDIN) – (UL-N)	57.7 ÷ 125 VAC	180 ÷ 250 VAC	300 ÷ 415 VAC
measuring range (UL-N)	3 ÷ 150 VAC	6 ÷ 300 VAC	10 ÷ 500 VAC
measuring range (UL-L)	5 ÷ 260 VAC	10 ÷ 520 VAC	20 ÷ 865 VAC
measuring uncertainty (tA=23±2°C)	+/- 0.05 % od rdg +/- 0.02 % of rng		
measurement category	150V CAT IV	300V CAT III	300V CAT III 600V CATII
permanent overload	300 VAC ( UL-N )	600 VAC ( UL-N )	1000 VAC ( UL-N )
peak overload (UL-N / 1 sec.)	400 VAC	800 VAC	1500 VAC
burden power, impedance	< 0.013 VA Ri = 1.8 MΩ	< 0.025 VA Ri = 3.6 MΩ	< 0.05 VA Ri = 6 MΩ

Current		
model	„X/100mA“	„X/5A“
INOM (IB) – rated current	0.1 AAC	1 / 5 AAC
measuring range	0.001 ÷ 0.39 AAC	0.005 ÷ 7 AAC
measuring uncertainty (tA=23±2°C)	+/- 0.05 % of rdg +/- 0.02 % of rng	
measurement category	150V CAT III	150V CAT III
permanent overload (IEC 258)	1 AAC	7.5 AAC
peak overload - for 1 second, max. repetition frequency > 5 minutes	10 AAC	70 AAC
burden power ( impedance)	< 0.01 VA ( Ri < 40 mΩ)	< 0.5 VA ( Ri < 10 mΩ)

Temperature (internal temperature sensor)	
measuring range	- 40 ÷ 80°C
measurement uncertainty	± 2 °C




Auxiliary Voltage			
model	„U“	„L“	„S“
range	85 ÷ 275 VAC / 40 ÷ 100 Hz 80 ÷ 350 VDC	20 ÷ 50 VAC / 40 ÷ 100 Hz 20 ÷ 75 VDC	10 ÷ 26 VAC / 40 ÷ 100 Hz 10 ÷ 36 VDC
power	8 VA / 3 W		
overvoltage cat.	III		
pollution degree	2		
connection	isolated, polarity free		

Digital Outputs & Digital Inputs		
„R“-Type Outputs (relay)		
type	N.O. contact	
load rating	250 VAC / 30 VDC, 4 A	
„I“- and „V“- Type Outputs (solid state, opto-MOS)		
	„RR/RI/II“ Models	„V“ Models
typ	Opto-MOS, bipolar	Opto-MOS, unipolar
load rating	60 VAC / 100 VDC, 100 mA	
dynamic param. (pulse output) :	SO - compatible	
- pulse duration	50 ms	
- gap duration	>= 50 ms	
- maximum frequency	10 Hz	
Digital Inputs		
	„RR/RI/II“ Models	„V“ Models
type	optoisolated, bipolar	optoisolated, unipolar
maximum voltage	100 VDC // 60 VAC	35 VDC
voltage for "logical" 0 / 1	< 3 VDC / > 10 VDC	< 3 VDC / > 10 VDC
input current	1 mA @ 10V / 5 mA @ 24V / 10 mA @ 48V	3 mA @ 10V / 13 mA @ 24V / 20 mA @ 35V
dynamic par. (pulse counter) :		
- pulse/gap duration	>= 50 / 50 ms	>= 0.5 / 0.5 ms
- maximum frequency	10 Hz	1 kHz


Other Specifications	
operational temperature	- 20 to 60°C
storage temperature	- 40 to 80°C

operational and storage humidity	< 95 % - non-condensable environment
EMC – immunity	EN 61000 – 4 - 2 ( 4kV / 8kV ); EN 61000 – 4 - 3 ( 10 V/m up to 1 GHz ); EN 61000 – 4 - 4 ( 2 kV ); EN 61000 – 4 - 5 ( 2 kV ); EN 61000 – 4 - 6 ( 3 V ); EN 61000 – 4 - 11 ( 5 periods )
EMC – emissions	EN 55011, class A EN 55022, class A (not for home use )
remote communication port (option)	RS-485 / 2400÷460800 Bd / protocols PQ PLUS, Modbus-RTU or Ethernet 10 Base-T / DHCP, webserver, Modbus-TCP or M-Bus (max. 9600 Bd)
display	Segment LCD FSTN with backlit
protection class : front panel back panel	IP 40 ( IP 54 with cover sheeting ) IP 20
dimensions : front panel built-in depth installation cutout	96 x 96 mm 80 mm 92 <sup>+1</sup> x 92 <sup>+1</sup> mm
mass	max. 0.3 kg


UMD 96 U 230 X/5A Typical Installation  
 TN-Network, Direct Star ("3Y") Connection



UMD 96... RI - Digital I/O Connection Example



### UMD 96 ... V – Digital I/O Connection Example



### Maintenance, Service

UMD 96 instruments do not require any maintenance. For reliable operation you only have to comply with the operating conditions specified and prevent mechanical damage to the instrument.

In the event of the product's breakdown, you have to return it to the supplier at their address.

The product must be packed properly to prevent damage in transit. Description of the problem or its symptoms must be sent along with the product. If warranty repair is claimed, the warranty certificate must be sent in too. If after-warranty repair is requested, a written order must be included.

### Warranty Certificate

Warranty period of 24 months from the date of purchase, however no later than within 30 months from the dispatch date from manufacturer's warehouse, is provided for the instrument. Problems in the warranty period, evidently caused by poor workmanship, design or inconvenient material, will be repaired free of charge by the manufacturer or an authorized servicing organization.

The warranty becomes void even within the warranty period if the user makes unauthorized modifications or changes to the instrument, connects it to out-of-range quantities if the instrument is damaged in out-of-specs impacts or from improper handling or if it has been operated in conflict with the technical specifications.