


Download data sheet



MM (Modbus Master)

This firmware extension collects Modbus data from connected slaves and places it in new register addresses on the master. The slave data can be shown on the display of the master with some built-in door devices and can also be stored with some devices. The MM is required, for example, when using our IO-M extension modules or when connecting feeder measurements.



Designation	Mapping	Display	Saving	Availability	Order no.
MM	•	-	-	UMD 705E, UMD 807E	55.21.1340
	•	-	•	MMB 700, UMD 707, UMD 709, UMD 710	
	•	•	•	UMD 97E, UMD 98, UMD 913	