



Download data sheet




## RCS (Ripple Control Signals)

The RCS module (for mains or signal voltage) activates the option to detect, evaluate, decode and save different ripple control signals on the monitored current network. The signal frequency can be adjusted manually. The signals are decoded and archived in the internal memory. The signal level can also be displayed live on devices with displays.



RCS			
Urc [V]	L1	L2	L3
act	0.2	0.2	0.2
avg	0.2	0.2	0.2
Last telegram L1			
avg1	0.0		
max1	0.0		
min1	0.0		
time	01.01.00 02:00:00		
frq	216.7Hz		
Trig. Urc	1.0V		



Designation	Description	Availability	Order no.
RCS	Ripple control signals	See technical specifications	54.21.1340